MULTISYNC II PCB

VIDEO DISPLAY

COMP SYNC

CERONIX DISPLAY

J10 GND BLUE GREEN RED

J1 +12V -12V GND GND GND GND +5V +5V +5V

J4 GND (DB11) WING L GND (DB12) WING R (DB9) REVERSE KEY

J5 LAMPS (DB0) ABORT GND KEY (DB1) START GND

WING L WING R REVERSE SEAT ADJUST ABORT START KEY KEY

MICS

J13 KEY GND AMBMIC GND VOCMIC KEY VREF GND

J6 +5V D1 D0 GND KEY

J9 KEY (CC2) SELF TEST GND CC 1 COIN 1 COIN 2 GND

J8 KEY GND +5V +5V (IN1) HOOD (POT) GND (IN0) GAS +5

J12 +5V (IN4) ELEVATOR GND (IN3) COIN VOL SGB.IN GND KEY

GND -22V/-12V +5V +12V -22V/-12V GND

AMB MIC

VOC MIC

HOOD ASSY

MOTOR

GAS

BRAKE (SG)

STARTER

FLOUR. LIGHT

XFORMER

F2

TB1

SWITCH PLATE

BALLAST

P24

P25

(NC) SEAT ADJ. ABORT WINGS L

WINGS R START REV

#658 LAMPS

CONTROL PANEL

TO MULTI II

LAMPS

FAN 120V L1 NEUTRAL SPOT NEUTRAL NEUTRAL 120V L2 NEUTRAL NEUTRAL 120V L3 PLAMP3 PLAMP4

GND +12V +5V

TO MULTISYNC II

MOTOR DRIVER PCB

MOTOR ASSY

STEERING OPTO

ELEVATOR

SELF-TEST

VOLUME CONTROL

COIN DOOR

SW GND RIGHT COIN SW LEFT COIN SW GND +5V CHASSIS GROUND

CCI +12V

COIN BOX

POWER SUPPLY

+12V 2A -12V .5A GND GND +5V 10A +5V 10A FG AC AC

SPEAKER PANEL

DSIII PCB

J3 J2 +5V VOLUME GND

J4 GND -22V/-12V +5V +12V -22V/-12V GND

** 18G SPEAKER WIRE
** 22G MIC WIRE

HARD DRIVIN'
AIRBORNE
9/16/93